



**SPARE PARTS / ERSATZTEILE / PIEZAS DE REPUESTO / ЗАПАСНЫЕ ЧАСТИ / RESERVE
ONDERDELEN / PEZZI DI RICAMBIO**


1	Embase Texas / Texas plug	51528
2	Clavier TIG / TIG keypad	51996
3	Circuit IHM / HMI circuit	E0109C
4	Transformateur HF / HF transformer	63818
5	Circuit fond de panier / Backplane circuit	E0106C
6	Circuit microcontrôleur / Microcontroller circuit	E0107C
7	Circuit HF/ HF circuit	E0204C
8	Circuit alimentation auxiliaire / Auxiliary power supply circuit	E0113C
9	Electrovanne 2 voies / 2-way solenoid valve	70991
10	Interrupteur triphasé / Three-phase switch	51062
11	Circuit connecteur groupe froid / Cooling unit connector circuit	E0111C
12	Ventilateur / Fan	50999
13	Circuit Primaire / Primary circuit	E0110C
14	Module pont de diode / Diode bridge module	52196
15	Module IGBT / IGBT module	52203
16	Diode rapide 2X120A / Fast diode 2X120A	52197
17	Capteur de courant / Current sensor	64463
18	Transformateur torique / Toroidal transformer	63816
19	Self de mode commun / Common mode self	63601

**INTERRUPTEUR VRD / VRD SWITCH / VRD-EIN-AUS-SCHALTER / INTERRUPTOR VRD /
VRD SCHAKELAAR / INTERRUETTORE VRD**

CIRCUIT DIAGRAM / SCHALTPLAN / DIAGRAMA ELECTRICO / ЭЛЕКТРИЧЕСКАЯ СХЕМА / ELEKTRISCHE SCHEMA / SCHEMA ELETTRICO

