


PPB 1020/2.5 – PPB 1270/2



Onderdeel lijst PBB1020/2A PBB1270/2A

Part #	Description	Q'ty	Part #	Description	Q'ty
1	ADJUSTING NUT	2	27	TREAD PLATE RUBBER	1
2	CLAMPING LEAF	1	28	ROLL PIN	2
3	T-NUT M10-1.5	20	29	EXT RETAINING RING 10MM	1
4	UPPER FINGERS	11	30	FOOT PEDAL LOCK	1
5	CAP SCREW M10-1.5X20	38	31	SPRING PIN 8X50	1
6	CLAMPING BLOCK	1	32	FLAT WASHER 8MM	1
7	ADJUSTING NUT SPRING	2	33	PEDAL LOCK SPRING	1
8	FLAT WASHER 20MM	6	34	LOWER SEGMENT	2
9	GREASE FITTING 8MM	2	35	SPRING PIN 10X50	2
10	BUSHING	2	36	SPRING PIN 10X50	2
11	FLAT WASHER 30MM	2	37	O-RING 33X25	2
12	FOLDING LEAF PIN	1	38	SETBACK KNOB	2
13	CAP SCREW M10-1.5X35	1	39	HEX BOLT M8-125X15	2
14	STOP COLLAR	1	40	BENDING LEAF	1
15	HEX NUT M10-1.5	1	41	BOLT	2
16	CAP SCREW M10-1.5X40	1	42	HEX. BOLT M12-1.75X150	2
17	LEG	1	43	STAR WASHER M12	2
18	EXT RETAINING RING 25MM	13	44	LOWER BLADE FITTING	1
19	LEG PIN	3	45	BOTTOM TELESCOPING STRUT	1
20	CAP SCREW M10-1.5X30	4	46	SPIRAL BLOCK	1
21	EXTENSION BRACKET	2	47	SPRING	1
22	DISC SPRING 40X20X1X2.4	4	48	TOP TELESCOPING STRUT	1
23	ROD	2	49	BUSHING	1
24	FOOT PEDAL LEVER	4	50	SHIM RING	1
25	LEVER PIN	4	51	CRANK	2
26	FOOT PEDAL	1			